

Directions for GARMIN gps unit (model #GPSmap78)

Power on:

- Press and hold red power button to turn on.
- Wait about one minute for gps unit to connect to satellites.

MAP screen:

- Press the PAGE button multiple times to toggle to the MAP.
- Press the + or – buttons to zoom in and out as needed; a distance scale will be displayed at the top of the screen.

Creating a waypoint:

- Mark the location of a potentially invasive aquatic plant, like Eurasian watermilfoil.
- On the MAP screen, press and hold the ENTER button, and then tap the ENTER button again.
- The gps unit will give the waypoint a generic sequential name like "031".

Need to delete a waypoint?

- Tap the MENU button twice to get to the Main Menu, and then choose "Waypoint Mgr".
- Select the name of the waypoint you need to delete and press ENTER.
- Tap the MENU button once, then choose "Delete".
- Confirm delete by moving to "Yes" and pressing ENTER.

Navigating to a previously-created waypoint:

- Go to the MAP screen.
- Use the + or – buttons to zoom in as needed on the MAP.
- Use the directional pad to move the cursor to the desired waypoint on the MAP.
- When the cursor is on top of the waypoint, it will highlight the waypoint, and its name will be displayed at the top of the screen.
- Tap the ENTER button. You will see the waypoint name as well as date and time information. You will see "GO" highlighted at the bottom of the screen.
- Tap the ENTER button again to select "GO". The gps unit will direct you to navigate to the location. As before, use the + or – buttons to zoom in as needed to help you navigate to the desired location on the MAP.

Power off:

- Press and hold red power button.